



VERTEC VT4889 V4 PRESETS

dbx DriveRack 4800

		INPUT 1	INPUT 2	INPUT 3	INPUT 4
3-WAY STEREO + AUX					
VT4889 3WX	1	AUX (FULLRANGE)	4889 LOW	4889 MID	4889 HI
				AUX (FULLRANGE)	4889 LOW
					4889 MID
					4889 HI
4-WAY STEREO					
4889 + 4881A X	2	4881A	4889 LOW	4889 MID	4889 HI
4889 + 4881A 60	3	4881A	4889 LOW	4889 MID	4889 HI
4889 + 4881A 80	4	4881A	4889 LOW	4889 MID	4889 HI
4889 + 4882 X	5	4882	4889 LOW	4889 MID	4889 HI
4889 + 4882 60	6	4882	4889 LOW	4889 MID	4889 HI
4889 + 4882 80	7	4882	4889 LOW	4889 MID	4889 HI
4889 + 4880 X	8	4880	4889 LOW	4889 MID	4889 HI
4889 + 4880 60	9	4880	4889 LOW	4889 MID	4889 HI
4889 + 4880 80	10	4880	4889 LOW	4889 MID	4889 HI
4889 + 4880A X	11	4880A	4889 LOW	4889 MID	4889 HI
4889 + 4880A 60	12	4880A	4889 LOW	4889 MID	4889 HI
4889 + 4880A 80	13	4880A	4889 LOW	4889 MID	4889 HI
4-WAY / AUX SUB + 3-WAY					
89 / 80 + 80 X + 89	14	4880	4880	4889 LOW	4889 MID
89 / 80 + 80 60 + 89	15	4880	4880	4889 LOW	4889 MID
89 / 80 + 80 80 + 89	16	4880	4880	4889 LOW	4889 MID
89 / 80A + 80A X + 89	17	4880A	4880A	4889 LOW	4889 MID
89 / 80A + 80A 60 + 89	18	4880A	4880A	4889 LOW	4889 MID
89 / 80A + 80A 80 + 89	19	4880A	4880A	4889 LOW	4889 MID
89 / 80 + 80 X + 88	20	4880	4880	4889 LOW	4889 MID
89 / 80 + 80 60 + 88	21	4880	4880	4889 LOW	4889 MID
89 / 80 + 80 80 + 88	22	4880	4880	4889 LOW	4889 MID
89 / 80A + 80A X + 88	23	4880A	4880A	4889 LOW	4889 MID
89 / 80A + 80A 60 + 88	24	4880A	4880A	4889 LOW	4889 MID
89 / 80A + 80A 80 + 88	25	4880A	4880A	4889 LOW	4889 MID
4-WAY + DOWN (DF) / OFFSTAGE FILL (2WX)					
89 / 87 + 80 X + 87	26	4880	4889 LOW	4889 MID	4889 HI
89 / 87 + 80 60 + 87	27	4880	4889 LOW	4889 MID	4889 HI
89 / 87 + 80 80 + 87	28	4880	4889 LOW	4889 MID	4889 HI
89 / 87 + 80A X + 87	29	4880A	4889 LOW	4889 MID	4889 HI
89 / 87 + 80A 60 + 87	30	4880A	4889 LOW	4889 MID	4889 HI
89 / 87 + 80A 80 + 87	31	4880A	4889 LOW	4889 MID	4889 HI
89 / 87A + 80 X + 87A	32	4880	4889 LOW	4889 MID	4889 HI
89 / 87A + 80 60 + 87A	33	4880	4889 LOW	4889 MID	4889 HI
89 / 87A + 80 80 + 87A	34	4880	4889 LOW	4889 MID	4889 HI
89 / 87A + 80A X + 87A	35	4880A	4889 LOW	4889 MID	4889 HI
89 / 87A + 80A 60 + 87A	36	4880A	4889 LOW	4889 MID	4889 HI
89 / 87A + 80A 80 + 87A	37	4880A	4889 LOW	4889 MID	4889 HI
4-WAY + DOWN (DF) / DISTRIBUTED FILL (2W)					
89 / 87 + 80 X + 87 F	38	4880	4889 LOW	4889 MID	4889 HI
89 / 87 + 80 60 + 87 F	39	4880	4889 LOW	4889 MID	4889 HI
89 / 87 + 80 80 + 87 F	40	4880	4889 LOW	4889 MID	4889 HI
89 / 87 + 80A X + 87 F	41	4880A	4889 LOW	4889 MID	4889 HI
89 / 87 + 80A 60 + 87 F	42	4880A	4889 LOW	4889 MID	4889 HI
89 / 87 + 80A 80 + 87 F	43	4880A	4889 LOW	4889 MID	4889 HI
89 / 87A + 80 X + 87A F	44	4880	4889 LOW	4889 MID	4889 HI
89 / 87A + 80 60 + 87A F	45	4880	4889 LOW	4889 MID	4889 HI
89 / 87A + 80 80 + 87A F	46	4880	4889 LOW	4889 MID	4889 HI
89 / 87A + 80A X + 87A F	47	4880A	4889 LOW	4889 MID	4889 HI
89 / 87A + 80A 60 + 87A F	48	4880A	4889 LOW	4889 MID	4889 HI
89 / 87A + 80A 80 + 87A F	49	4880A	4889 LOW	4889 MID	4889 HI

NOTES:

Preset 1	Stereo 3-Way with AUX / FULLRANGE Outputs (flat, gain at -infinity)
Presets 2-13	Stereo 4-Way Presets
Presets 14-19	4-Way (AUX SUB DRIVE OPTION or FLOWN/GROUND STACKED SUBS) + 4889 3WX
Presets 20-25	4-Way (AUX SUB DRIVE OPTION or FLOWN/GROUND STACKED SUBS) + 4888 3WX
Presets 26-31	4-Way + DOWNFILL (4887 DF) + OFFSTAGE FILL (4887 in 2WX mode)
Presets 32-37	4-Way + DOWNFILL (4887A DF) + OFFSTAGE FILL (4887A in 2WX mode)
Presets 38-43	4-Way + DOWNFILL (4887 DF) + DISTRIBUTED FILL (4887 in 2W mode)
Presets 44-49	4-Way + DOWNFILL (4887A DF) + DISTRIBUTED FILL (4887A in 2W mode)